

For long lasting durability and best possible protection for your tent, follow these simple tips:

Hand wash the canopy using **ONLY** mild soap and water. Never use harsh detergents, abrasives, bleach or any other chemicals.

DO NOT MACHINE WASH!

Never fold or store your tent when it is damp or wet. Let it dry completely to avoid mildew.

It is recommended to occasionally wipe frame with a silicone spray, especially before and after use in damp conditions. This helps the frame to operate more smoothly and gives it that extra clean look. Be sure to remove excess silicone residue before putting the canopy on.

ISSUES WITH SETUP CONTACT US AT

1-866-308-TENT (8368)

OR

HELP@DISPLAYBUILDS.COM

TENTS

OWNER'S GUIDE



Scan the QR code or visit the web address directly to view the **assembly video** and for further assistance:
displaybuilds.com/tents



**SET-UP &
SAFETY
INSTRUCTIONS**

**IMPORTANT INFORMATION
(READ CAREFULLY BEFORE SETTING UP YOUR TENT)**

Use caution when handling the tent folding frame. We suggest that you take your time and be sure not to bend the frame. In addition, avoid pinching hands or fingers as frame opens or closes.

Avoid setting up your tent on steep inclines.

Always be sure to use the guy ropes and stakes provided to secure your tent to the ground and avoid shelter use in any potentially windy or rainy weather. Wind and rain can damage the tent and may also result in injury to you or others.

Do not use your tent for permanent shelter. It is designed for temporary use only. Do not leave up for extended periods of time.

Do not rely on shelter for protection in heavy or prolonged rain storms.

Do not use shelter in lightning storms.

Keep your canopy away from heat and flames at all times. Do not use barbecues or fires underneath your tent.

Never leave your tent unattended.

- (1) Frame Fully Assembled
- (1) Canopy (SOMETIMES PACKED WITH FRAME, SOMETIMES SEPARATELY PACKED)
- (1) Carry-All Bag
- (1) Four Piece Stake Set with Guy Ropes

**WHAT'S
INCLUDED**

**SET-UP
INSTRUCTIONS**

1. Place your frame in the center of the area to be sheltered with feet of frame at bottom. With another person on the opposite side, grasp the legs of the frame until it is extended a full arms length, approximately 4 feet. Be careful not to pinch your fingers. **ONLY USE THE CORNER LEDGE TO PULL FRAME APART, DO NOT BEND THE ACCORDION SECTIONS OF THE FRAME.**

2. At each corner, hold the leg of the frame with one hand and lift the black slider with the other hand. Pull until the locking pin slides and locks into place.

3. Unfold the fabric canopy and place it over the open frame. Gently pull four corners of the canopy to its proper position.

4. Attach the canopy to the frame by means of the Velcro fastening strips and/or ties (where applicable). Fastening strips and/or ties are located in all four corners of the canopy and Velcro fastening strips are also in the mid-section areas. Please be sure that your canopy is securely attached to the frame.

**SET-UP
INSTRUCTIONS
(CONTINUED)**



Scan the QR code or visit the web address directly to view the **assembly video** and for further assistance: displaybuilds.com/tents



5. Once canopy is firmly attached to frame, slightly lift up the two adjacent outer legs and slide out the inner legs until the snap button locks. Be sure that the button is locked in place. Repeat this process on the opposite adjacent legs. **MAKE SURE TO DO TWO LEGS AT A TIME.**

Note: The adjustable legs offer multiple height levels. Be sure that the elected height level is the same on each leg.

6. Use the stakes and guy ropes provided to secure the canopy to the ground by way of metal rings which are located on all four corners of the canopy. This ensures that your canopy will not incur wind damage during proper use.

Helpful Hint: You may want to place the guy ropes in position while the frame is in a lower position.

7. You are now ready to enjoy your tent.

**TAKE-DOWN
INSTRUCTIONS**

1. Untie guy ropes and remove stakes from ground and place these items in the small carry bag provided. Unfasten the Velcro fastening strips and/or ties (where applicable).

2. With help from another individual, slightly lift up two adjacent outer legs, push the button down and telescope the inner legs up into the outer legs until they are at the shortest positions. Repeat on the opposite adjacent legs (**MAKE SURE TO DO TWO LEGS AT A TIME**).

3. At each corner pull the locking pin on the black slider and pull the slider down slowly until the button pops out above the slider.

4. Once in lowered position, remove the canopy.

5. While in lower position (with individuals on opposite sides of frame), lift the shelter up slightly and shake it while stepping towards your partner until the unit is 3/4 of the way closed. With each individual grasping two outer legs, push frame together to fully close it. Store your frame in the carry bag provided. **BE CAREFUL NOT TO PINCH YOUR FINGERS!**