




# Pringles Glides - Assembly Instructions




GLIDE TRAY

3 PUSH PIN


**1** First place one (A) Glide Tray onto the shelf and align the edge of the tray with the edge of the shelf. Next move the tray forward or backward to align the front of the tray with the front of the shelf. Make sure oval slots on (A) Glider Tray align with the triangle slots.



**2** Install eight (B) Push Pins by locating holes aligned with both the (A) Glide Tray and the shelf. Install by inserting (B) Push Pin into hole and pressing down to lock into place.



**3** Repeat steps 1 and 2 to install additional Glide Trays on additional shelves.



## Pringles Glides - Assembly Instructions



### MISSING PARTS / DAMAGE CLAIM INSTRUCTIONS

**1. DO NOT discard the box or original packaging.**

In the case of damaged goods caused by shipping, photo evidence will be required.

**2. Take photos of the box & markings.**

A photo of the markings (text) on the side of the box is required for all cases in which a replacement part is needed. This helps to identify the item number and ensures the correct parts are pulled.

**3. Take photos of damage (if applicable).**

A photo of the damaged part(s) is always required to file a claim and expediently process the replacement part. Please make sure you keep the box even if it is damaged.

**4. Send an email with the images requested.**

Email a description of the claim along with the images required above directly to [parts@tmaksinc.com](mailto:parts@tmaksinc.com). Call our toll-free number 1-866-308-8368 for further assistance.