
Coca-Cola Dollar General 3x1 Floor Display - Assembly Instructions



For customer service or parts, please call our toll free number 1-866-308-8368 or email help@displaybuilds.com.

JOB 17781

Scan the QR code or visit the web address directly to view the assembly video: displaybuilds.com/instructions_17781



MISSING PARTS / DAMAGE CLAIM INSTRUCTIONS

1. <u>DO NOT</u> discard the box or original packaging.

In the case of damaged goods caused by shipping, photo evidence will be required.

2. Take photos of the box & markings.

A photo of the markings (text) on the side of the box is required for all cases in which a replacement part is needed. This helps to identify the item number and ensures the correct parts are pulled.

3. Take photos of damage (if applicable).

A photo of the damaged part(s) is always required to file a claim and expediently process the replacement part. Please make sure you keep the box even if it is damaged.

4. Send an email with the images requested.

Email a description of the claim along with the images required above at displaybuilds.com/contact or directly to <u>help@displaybuilds.com</u>. Call our toll-free number 1-866-308-8368 for further assistance.