

Coca-Cola Mini Can Pop Up Display - Assembly Instructions





Scan the QR code or visit the web address directly to view the **assembly video**: displaybuilds.com/instructions_17804



<p>A</p> <p>Display</p>	<p>B</p> <p>Header</p>	<p>C</p> <p>Logo</p>	<p>D</p> <p>Bolt</p>	<p>E</p> <p>Allen Key</p>
--------------------------------	-------------------------------	-----------------------------	-----------------------------	----------------------------------


1 Attach (B) Header to (A) Display with x2 (D) Bolts and tighten with (E) Allen Key.

2 Attach (C) Logo to (B) Header with x1 (D) Bolt and tighten with (E) Allen Key.



PRECAUTIONS

- **Maximum load weight: 178 lbs**
- Keep display dry and stored in a temperature/humidity controlled environment to prevent warping of wood components which could lead to malfunction.
- Packaging for products placed on the display must be in new and good condition. Torn or deformed boxes could lead to malfunction of the display and/or unstable stacked product.
- Inspect the metal body of the (A) Display to ensure it is not damaged or dented, as this could impact the functionality of the internal components.
- If the moving mechanism becomes stuck, check the (1) packaging for damage that could cause it to get hung up and (2) the display body to ensure it is not damaged.
- The springs will wear over time and begin to have less tension; therefore it is normal for the height in which the product rises to decrease over time.
- It is normal to hear some noise as the display operates.





Scan the QR code or visit the web address directly to view the **assembly video**: displaybuilds.com/instructions_17804



MISSING PARTS / DAMAGE CLAIM INSTRUCTIONS

1. DO NOT discard the box or original packaging.

In the case of damaged goods caused by shipping, photo evidence will be required.

2. Take photos of the box & markings.

A photo of the markings (text) on the side of the box is required for all cases in which a replacement part is needed. This helps to identify the item number and ensures the correct parts are pulled.

3. Take photos of damage (if applicable).

A photo of the damaged part(s) is always required to file a claim and expediently process the replacement part. Please make sure you keep the box even if it is damaged.

4. Send an email with the images requested.

Email a description of the claim along with the images required above at displaybuilds.com/contact or directly to help@displaybuilds.com. Call our toll-free number 1-866-308-8368 for further assistance.