












# Four Loko Pregame Floor Display - Assembly Instructions



Scan the QR code or visit the web address directly to view the **assembly video**: [displaybuilds.com/instructions\\_18230](http://displaybuilds.com/instructions_18230)




# Four Loko Pregame Floor Display - Assembly Instructions


Scan the QR code or visit the web address directly to view the **assembly video**: [displaybuilds.com/instructions\\_18230](http://displaybuilds.com/instructions_18230)





- 5** Install assembled (E) Shelves in order shown by inserting the tab through the top slot in the (A) Display and resting the front on the (F) Support Bar.



- 6** On the back of the (A) Display, fold the tab on the back of each (E) Shelf down and lock into the bottom slot.



- 7** Insert (B) Header into (A) Display.



## MISSING PARTS / DAMAGE CLAIM INSTRUCTIONS

**1. DO NOT discard the box or original packaging.**

In the case of damaged goods caused by shipping, photo evidence will be required.

**2. Take photos of the box & markings.**

A photo of the markings (text) on the side of the box is required for all cases in which a replacement part is needed. This helps to identify the item number and ensures the correct parts are pulled.

**3. Take photos of damage (if applicable).**

A photo of the damaged part(s) is always required to file a claim and expediently process the replacement part. Please make sure you keep the box even if it is damaged.

**4. Send an email with the images requested.**

Email a description of the claim along with the images required above at [displaybuilds.com/contact](http://displaybuilds.com/contact) or directly to [help@displaybuilds.com](mailto:help@displaybuilds.com). Call our toll-free number 1-866-308-8368 for further assistance.