



KDP DG Football Display - Assembly Instructions


Scan the QR code or visit the web address directly to view the assembly video: displaybuilds.com/instructions_18329




1 Assemble all (F) 12 Pack Tray (G) Bottom Shelves, and (H) Shelves by folding as shown. Place (K) 12 Pack Tray Liner in the bottom of the assembled (F) 12 Pack Tray.




2 Arrange (A), (B), (C), & (D) Side Panels; (G) Bottom Shelves; and (F) 12 Pack Tray as shown below. Connect all with (L) Fasteners. Fasten (A) & (D) Side Panels to (G) Bottom Shelf on each end of the display; Fasten (B) & (C) Side Panels, (G) Bottom Shelf, and (F) 12 Pack Tray in both center locations.




3 Fold (I) 2L Shelf Divider and (J) 6Pk Shelf Divider and insert into the (G) Bottom Shelf on the corresponding side as shown, locking the tabs on the sides of the Dividers into the Side Panels.



4 Install x2 (M) Short Support Bars on each side of the display.



5 Install a (H) Shelf on each side of the display by inserting the tabs on the sides into the corresponding slots on the inside of each Side Panel, and resting the shelf on the (M) Support Bars and (I) & (J) Divider below it.







Scan the QR code or visit the web address directly to view the assembly video: displaybuilds.com/instructions_18329




6 Continue layering (I) & (J) Dividers, (M) Support Bars, and (H) Shelves. Note the 6Pk side will hold an additional layer.



7 Place the (N) Long Support Bar across the center, connecting the two inner Side Panels.



8 Place the (E) Top Tray on the assembled display and insert the tabs on the Side Panels through the bottom. Fold the tabs all the way over and insert into the other slot to lock into place.







Scan the QR code or visit the web address directly to view the assembly video: displaybuilds.com/instructions_18329



9 Finalize (E) Top Tray Assembly by folding up the short ends and the tabs inward. Then fold over the long sides, inserting the tabs to lock into place. Finalize by tucking the centers into the middle.



MISSING PARTS / DAMAGE CLAIM INSTRUCTIONS

1. **DO NOT** discard the box or original packaging.
In the case of damaged goods caused by shipping, photo evidence will be required.
2. Take photos of the box & markings.
A photo of the markings (text) on the side of the box is required for all cases in which a replacement part is needed. This helps to identify the item number and ensures the correct parts are pulled.
3. Take photos of damage (if applicable).
A photo of the damaged part(s) is always required to file a claim and expediently process the replacement part. Please make sure you keep the box even if it is damaged.
4. Send an email with the images requested.
Email a description of the claim along with the images required above at displaybuilds.com/contact or directly to help@displaybuilds.com. Call our toll-free number 1-866-308-8368 for further assistance.